



**Notes:**

1. Do not scale drawing.
2. Right hand shown.
3. It is the door and frame manufacturers' responsibility to check the hardware schedule and prepare doors and frames.
4. Pivots drilled for 1/4-20 x3/4" FHMS or #14 x 1-1/2" FHWS.
5. Suitable reinforcing by others.
6. Doors must be radiused. Radius is determined by pivot point to the frame, less 1/16" (1.6). On the 127-3/4, that is fixed at 1-1/4" (31.8). The 128-3/4 pivot point can be moved toward the lock edge.
7. 5/16" (7.9) min., 3/4" (19) max. clearance. If more clearance is needed, longer spindle is required.
8. All dimensions are in inches (mm).

## 127-3/4 and 128-3/4 Pivot Set Center Hung

**RIXSON®**

**ASSA ABLOY**

www.rixson.com

TEMPLATE NUMBER

**PS30200**

DATE

**12-11**