

T2 – DL2700 Programming - Cheat Sheet

Factory Code = 12345

1. **Change Factory code to the new Master code.** (Must be 3-5 digits in length.)

1	2	3	4	5	A _L	1	A _L		A _L	
								(Enter Master Code)	(Re Enter Master Code)	

2. **Create Manager Code** (Code length must be the same as the master code)

Master Code	A _L	2	A _L	
(Enter Manager Code)				

3. **Add User Code(s)** (Code length must be the same as the master code)

Bank 1

User 1	Master or Manager code	A _L	11	A _L	
User 2	Master or Manager code	A _L	12	A _L	
User 3	Master or Manager code	A _L	13	A _L	
User 4	Master or Manager code	A _L	14	A _L	
User 5	Master or Manager code	A _L	15	A _L	

(Enter User Code)

Bank 2

User 1	Master or Manager code	A _L	21	A _L	
User 2	Master or Manager code	A _L	22	A _L	
User 3	Master or Manager code	A _L	23	A _L	
User 4	Master or Manager code	A _L	24	A _L	
User 5	Master or Manager code	A _L	25	A _L	

(Enter User Code)

Bank 3

User 1	Master or Manager code	A _L	31	A _L	
User 2	Master or Manager code	A _L	32	A _L	
User 3	Master or Manager code	A _L	33	A _L	
User 4	Master or Manager code	A _L	34	A _L	
User 5	Master or Manager code	A _L	35	A _L	

(Enter User Code)

4. **1 Time Code** (Replaces Bank 3 User 5)

Master or Manager code	A _L	3	A _L	
------------------------	----------------	---	----------------	--

(Enter User Code)

5. **Passage Mode**

Master Code	A _L	4	A _L	
-------------	----------------	---	----------------	--

6. **Re-Lock**

Master Code	A _L	5	A _L	
-------------	----------------	---	----------------	--

7. **Disable Banks**

Bank 1	Master or Manager code	A _L	51	A _L	
Bank 2	Master or Manager code	A _L	52	A _L	
Bank 3	Master or Manager code	A _L	53	A _L	

8. **Re-Enable Banks**

Bank 1	Master or Manager code	A _L	41	A _L	
Bank 2	Master or Manager code	A _L	42	A _L	
Bank 3	Master or Manager code	A _L	43	A _L	

9. **Disable/Re-Enable Individual User(s)**

Master or Manager code	A _L			A _L
------------------------	----------------	--	--	----------------

(Bank #) (User #)